


Instructions for installing T-P2X Master software

Download **T-P2X Master.zip** to a temporary location.

When installing for the first time, unzip **T-P2X Master.zip** to a folder called **C:\T-P2X Master** which should produce the file structure below (which can be checked using Windows Explorer).



File Name	Date	Time	Type	Size
Systems	03/03/2011	11:33	File Folder	
CommStudio.ocx	13/10/2005	21:32	ActiveX Control	720 KB
Demo System.cfg	01/03/2011	09:27	CFG File	1 KB
MSCOMCTL.OCX	08/03/2004	23:00	ActiveX Control	1,057 KB
MSFLXGRD.OCX	24/06/1998	00:00	ActiveX Control	239 KB
msvbvm60.dll	23/08/2001	13:00	Application Extens...	1,356 KB
T-P2X Master.bak	27/02/2011	15:08	BAK File	1 KB
T-P2X Master.ini	27/02/2011	15:08	Configuration Sett...	1 KB
T-P2X Master_V2_0_7.e...	24/02/2011	17:15	Application	496 KB
T-P2X Splash.ico	03/10/2005	20:50	Windows Icon	7 KB
T-P2X Viewer.exe	19/07/2010	10:46	Application	280 KB

Test the installation by running **T-P2X Master_V2_0_7.exe**. If a runtime error occurs check that the application is being run in Administrator mode.

T-P2X Master.zip contains a series of demonstration records in a folder called **Demo System** (see next page) which illustrate the basic controls and methods of display used by the **T-P2X Master** application

To update an earlier version of **T-P2X Master** in an existing **C:\T-P2X Master** folder, unzip **T-P2X Master.zip** to the existing **C:\T-P2X Master** folder and accept any prompts to overwrite existing files. All existing files and records will be retained. Modify the properties of any existing desktop shortcut to point to the latest version of the T-P2X Master application.

If the application has to be installed in a location other than **C:\T-P2X Master** the first line of **T-P2X Master.ini** must be modified to reflect the new location.

Details of records contained in Demo System folder

The records were obtained on a test box model of 200 metres of conventional 4 core cable with an open circuit fault on the Y phase and a short circuit to earth fault on the B phase. The R phase of the cable was energised at 240 volts.

Operation	Unit	Filename	Balance	Gain	Pulse	Range	Current FSD	Trigger Mode	Comments
Manual Test	Unit #250	11-03-01 10-07-38(R-N=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Test	Unit #250	11-03-01 10-09-30(R-N=Internal)	10	20	2	400	2	TDR Voltage Dip & Current	Gain too high
Manual Test	Unit #250	11-03-01 10-09-52(R-N=Internal)	10	0	2	400	2	TDR Voltage Dip & Current	Gain too low
Manual Test	Unit #250	11-03-01 10-10-23(R-N=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Gain Optimised
Manual Test	Unit #250	11-03-01 10-10-48(R-N=Internal)	10	10	1	400	2	TDR Voltage Dip & Current	Narrow Pulse
Manual Test	Unit #250	11-03-01 10-11-25(R-N=Internal)	10	10	8	400	2	TDR Voltage Dip & Current	Wide Pulse
Manual Test	Unit #250	11-03-01 10-11-49(R-N=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Optimised Pulse
Manual Test	Unit #250	11-03-01 10-12-03(R-N=Internal)	60	10	2	400	2	TDR Voltage Dip & Current	Internal Balance too high
Manual Test	Unit #250	11-03-01 10-12-31(R-N=Internal)	0	10	2	400	2	TDR Voltage Dip & Current	Internal Balance too low
Manual Test	Unit #250	11-03-01 10-14-01(R-N=Internal)	28	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Manual Test	Unit #250	11-03-01 10-15-35(Y-N=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Test	Unit #250	11-03-01 10-16-02(Y-N=Internal)	28	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Manual Test	Unit #250	11-03-01 10-16-40(Y-N=R-N)	R-N	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-17-05(B-N=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Test	Unit #250	11-03-01 10-17-27(B-N=Internal)	28	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Manual Test	Unit #250	11-03-01 10-17-47(B-N=R-N)	R-N	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-18-34(R-Y=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Test	Unit #250	11-03-01 10-19-50(R-Y=Internal)	52	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Manual Test	Unit #250	11-03-01 10-20-18(R-Y=B-Y)	B-Y	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-21-25(R-Y=R-B)	R-B	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-22-05(Y-B=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Test	Unit #250	11-03-01 10-22-33(Y-B=Internal)	52	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Manual Test	Unit #250	11-03-01 10-22-59(Y-B=R-B)	R-B	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-23-20(Y-B=Y-R)	Y-R	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-23-49(B-R=Internal)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Test	Unit #250	11-03-01 10-24-13(B-R=Internal)	52	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Manual Test	Unit #250	11-03-01 10-24-34(B-R=Y-R)	Y-R	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Manual Test	Unit #250	11-03-01 10-24-55(B-R=B-Y)	B-Y	10	2	400	2	TDR Voltage Dip & Current	External Balance against R-N
Triggered TDR	Unit #250	11-03-01 10-30-09(14)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Triggered TDR	Unit #250	11-03-01 10-32-55(15)	28	10	2	400	2	TDR Voltage Dip & Current	Internal Balance Optimised
Triggered TDR	Unit #250	11-03-01 10-35-47(17)	Y-N	10	2	400	2	TDR Voltage Dip & Current	External Balance against Y-N
Manual Trigger	Unit #250	11-03-01 10-37-23(MT)	10	10	2	400	2	TDR Voltage Dip & Current	Typical default settings
Manual Trigger	Unit #250	11-03-01 10-38-24(MT)	10	10	2	400	2	TDR Voltage Dip & Current	Marker unit at remote end
Manual Trigger	Unit #250	11-03-01 10-40-06(MT)	10	10	2	400	2	TDR Voltage Dip & Current	Marker unit at intermediate point
Manual Test	Unit #250	11-03-01 11-18-49(R-N=TRS)	10	10	2	400	2	TRS MASTER(Filter On)	Unit #249 set as TRS MASTER(Filter On)
Manual Test	Unit #250	11-03-01 11-22-17(R-N=TRS)	10	10	2	400	2	TRS SLAVE(Filter On)	Unit #249 set as TRS MASTER(Filter On)
Manual Test	Unit #250	11-03-01 11-22-45(R-N=TRS)	10	10	2	400	2	TRS MASTER(Filter On)	Unit #249 set as TRS SLAVE(Filter Off)
Manual TRS	Unit #250	11-03-01 11-12-56(MT)	10	10	2	400	2	TRS SLAVE(Filter On)	Unit #249 set as TRS MASTER(Filter On)
Manual TRS	Unit #250	11-03-01 11-15-59(MT)	10	10	2	400	2	TRS MASTER(Filter On)	Unit #249 set as TRS SLAVE(Filter On)
Manual TRS	Unit #250	11-03-01 11-16-51(MT)	10	10	2	400	2	TRS MASTER(Filter On)	Unit #249 set as TRS MASTER(Filter On)
Triggered TRS	Unit #250	11-03-01 11-50-21(02)	10	10	2	400	2	TRS MASTER(Filter On)	Unit #249 set as TRS MASTER(Filter On)
Triggered TRS	Unit #250	11-03-01 12-13-43(06)	10	10	2	400	2	TRS MASTER(Filter Off)	Unit #249 set as TRS MASTER(Filter Off)
Triggered TRS	Unit #249	11-03-01 11-50-20(07)	10	10	2	400	2	TRS MASTER(Filter On)	Unit #250 set as TRS MASTER(Filter On)
Triggered TRS	Unit #249	11-03-01 12-13-43(11)	10	10	2	400	2	TRS MASTER(Filter Off)	Unit #250 set as TRS MASTER(Filter Off)